







# HANGING CHAIR HARMONY



A		1 PC	G		2 PCS
B		4 PC	H		8 PCS
C		1 PC	J		2 PCS
D		1 PC	K		1 PC
			L		1 PC
			M		1 PC
E		1 PC	N		1 PC
			O		1 PC
F		1 PC	P		1 PC
			Q		1 PC
			R		1 PC



## MAINTENANCE AND CLEANING

1. CLEANING: WIPE WITH A DAMP CLOTH. DO NOT USE BLEACH, SOLVENTS OR ABRASIVE CLEANING AGENTS CLEANERS ON FRAME OR WICKER PARTS.
2. DURING THE CHANGEABLE WEATHER AND WINTER PERIOD WE STRONGLY RECOMMEND THAT THE CHAIR IS STORED IN A DRY PLACE UNDER A SUITABLE COVER. PLEASE MAKE SURE THE CHAIR IS DRY BEFORE STORING.
3. IF ANY DAMAGE APPEARS ON THE METAL PARTS, WE RECOMMEND USING A RUST REMOVER OR SIMILAR.
4. PERIODICALLY CHECK AND MAKE SURE THAT THE SCREWS ARE FULLY TIGHTENED.
5. IT IS ADVISABLE TO USE A SUITABLE COVER FOR THE FURNITURE IN ORDER TO PROLONG ITS FUNCTIONING.